

Fixings - 3 only (all diagrams shown for a right hander – for a left hander change top corners)



1. With the Otterbox Holster you get 2 straps and 3 fixing points.
2. There are only 3 fixing points because the fourth location (top corner) is left free
3. Whether left or right handed you place 2 fixings on the bottom two locations of the Otterbox and the third fixing goes on
4. the **Top Right for left handed people** and
5. the **Top Left for right handed people**.
6. Strap positions are shown for right handers –
7. First strap top left, diagonal to bottom right, goes over your shoulder or round your neck
8. Second strap – bottom left to bottom right goes around your waist

Strap one corner to corner goes over shoulder or around the neck

